






40005




1



2



2




1



2



3



4



6




5



7




8



9



10




11



12




1





2




13




14



15



16







1



2




3



2x

17







1




2




3



4




18





1



2



3



1



2



3



4



4



5




6




7




1




2



8




1




2



9



19





1x
370024



2x
300501



1x
4160228



1x
302301



2x
614101



1x
4244363



1x
368026



2x
395626



2x
366501



2x
4121932



1x
4540203



3x
4114084



1x
4118790



3x
4114309



1x
4155708



4x
4161734



4x
4109995



1x
4118866



2x
4211150



3x
4211201



4x
4211202



4x
4211221



2x
4508616



2x
4216625



5x
4225869



6x
4216695



2x
4211189



2x
4211242



7x
4211149



4x
4211210



4x
4216668



1x
4211225



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

www.lego.com/service or dial



00800 5346 5555 :



1-800-422-5346 :



FREE! GRATIS! GRATUIT!



club
MAGAZINE™

www.LEGOclub.com



00800 5346 5555

 1-866-534-6258 • 1-877-518-5346

US & Canada only

Canada seulement

* Freephone. Mobile charges may apply. * Numéro sans Frais. Des Frais peuvent s'appliquer avec les téléphones cellulaires.

* Gebührenfrei, Kosten für Anrufe aus Mobilfunknetzen können abweichen. * Gratis telefonnummer vanaf vaste lijn.

* Det er ett gratis nummer, när du ringer fra Posttelefon. * Det är gratis, när du ringer från en Post telefon.



VISIT THE WORLD'S
BIGGEST LEGO® SHOP!

www.LEGOshop.com

